

# 1/4" BRASS INSERT & DELRIN® SLEEVE

CONNECTS 1/4" POLY TUBING  
TO COMPRESSION FITTINGS  
AND VALVES



**CAUTION:** Turn off electricity at circuit breaker  
before working on evaporative cooler.

## Poly Tubing:

1. Cut the end of the tube square to insure proper fit.
2. Place nut onto poly tube.
3. Place Delrin® sleeve onto poly tube.
4. Place brass insert into end of tube.
5. Tighten nut with a wrench.

**⚠ WARNING:** Cancer and Reproductive  
Harm - [www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov).

**Not for Potable Water**

PN 9512 Form 99059-0519



[www.dialmfg.com](http://www.dialmfg.com) Made in China

© Copyright 2019 Dial Mfg., Inc. Phoenix, AZ