



**⚠ WARNING:** Motors must be connected to an overload protection device per requirements of the National Electrical Code to protect against overheating. Failure to do this will void the motor warranty.

All Dial 3 phase motors come with two NC thermostat wires which can be used in series with the stop switch to protect the motor if it overheats. See the electrical diagram below. If other overload protection is provided and thermostat wires are not needed, cap wires and leave in junction box.

